

Bullet Blender® 5

Homogenization Protocol for Epithelial Tissue

The protocol described in this document is for the use of the Bullet Blender® 5 for the homogenization of epithelial tissue (from a variety of animals). If you have difficulty with this protocol, cutting your tissue into smaller pieces will help. This protocol does not specify a particular buffer - you may choose which is most appropriate for your downstream application (nucleic acid isolation, protein extraction, etc.).

Materials Required: epithelial tissue, Bullet Blender® 5, homogenization buffer, pipettor, 5mL Axygen® brand tubes, and [3.2 mm stainless steel beads \(part number ZrOB20\)](#).

Instructions

1. Cut epithelial tissue into appropriately sized pieces for analysis (0.1g – 0.5g).
2. **OPTIONAL:** If desired, wash the tissue 3x with 5mL PBS to remove blood and other contaminants from the tissue.
3. Place sample in 5mL tube and add beads to the tube. Use a volume of beads equal to the mass of tissue. **NOTE:** 100mg \approx 100 μ L.
4. Add 0.2mL to 1.0mL buffer (2 volumes of buffer for every volume of sample).
5. *Tightly* screw the centrifuge tubes closed and place them into the Bullet Blender®.
6. Set controls for **SPEED 9** and **TIME 4** minutes. Press start.
7. After the run, remove the tubes from the instrument.
8. Visually inspect samples, if homogenization is unsatisfactory, run for another three minutes at **SPEED 9**.
9. Proceed with your downstream application.

SAFETY NOTE!!!

When using a centrifuge to separate your homogenate from the debris and beads, make sure your tubes are balanced.

Date 05/06/2011



Quasar Instruments, LLC
4835 Centennial Blvd.
Colorado Springs, CO 80919